

DR. FEICKERT ANALOGUE

## PROTRACTOR N<sub>ext</sub>G<sub>eneration</sub>

Quick instructions:

- a** - choose geometry (Baerwald, Lofgren or Stevenson)
- b** - aim with ruler over the pivot of tonearm and fix it over the pivot point
- c** - adjust overhang that stylus tip touches down on the intersection point at area **step 1**
- d** - **now you don't need to aim over the pivot point anymore!**
- e** - adjust angular offset at the outer Null point / area **step 2**
- f** - check parallelity with lines on the inner Null point at area **step 3** resp.
- g** - in case parallelity doesn't match go back to point **b**, otherwise planar setup is finished

Enjoy your vinyl!

More information on:  
<http://www.feickert.com>  
<http://www.adjustplus.de>

copyright 2009, 2010, 2017, Dr. Christian Feickert

**red lines are auxiliary lines!**  
**black lines in the back are the  
hash marks for setup!**

